# SENTRILOCK Quick Tip Guide

### **Basic Lockbox Troubleshooting**

- 1. Ensure Key Compartment is fully latched. Press up on the key compartment. If properly latched, the key compartment should have some wiggle to it when pulling the tab at the bottom of the Lockbox.
- 2. Ensure the shackle is fully latched by pressing down firmly on the shackle. If it is latched properly, there should be a bounce/spring when pressing down on the shackle.
- 3. Press ENT + FNC + 59 + ENT to force latch the Lockbox and ensure no errors persist.
- 4. If an error occurs, repeat steps 1 and 2.

### Open Key Compartment via Bluetooth

- 1. Open the SentriKey Application and press **ENT** on the Lockbox, the app will request your PIN/Touch ID/Face ID and will retrieve Lockbox Information before opening.
- 2. If the app stalls or data issues occur, force close the application, press **ENT + FNC + ENT** on the Lockbox to stop advertising Bluetooth. Note: If the Lockbox is still connected to a device via Bluetooth, the keypad will not be responsive.
- 3. Open the SentriKey Application and re-attempt step 1.
- 4. Upon success, you may have to use the pull tab at the bottom of the Lockbox to pull down on the key compartment to fully open it.

## **Open Key Compartment via NFC:**

- 1. Open the SentriKey Application, Press Touch N Show. The Ready to Scan image will appear.
- 2. Touch your phone near the "8" and "0" Keys on the Lockbox for proper alignment. You may have to move the phone around on the Lockbox.
- 3. Once the Lockbox beeps and lights up, hold your phone to the Lockbox until the Key bin releases.
- 4. If done properly, the app will not prompt you for a PIN/Face ID/Touch ID.
- 5. If the app stalls or data issues occur, force close the application, press ENT + FNC + ENT on the Lockbox to stop advertising Bluetooth. Note: If the Lockbox is still connected to a device via Bluetooth, the keypad will not be responsive.
- 6. Open the SentriKey Application and re-attempt step 1-3.
- 7. Upon success, you may have to use the pull tab at the bottom of the Lockbox to pull down on the key compartment to fully open it.

#### **Release Shackle:**

- 1. Open the SentriKey Application, select My Lockboxes and Release Shackle.
- Press ENT on the Lockbox and the application will ask for your PIN/Touch ID/Face ID.
   A message will appear to hold the bottom of the Lockbox. The shackle will not release until you press OK.
- 3. The shackle release wizard will step you through assigning or removing your Lockbox from a listing.